



BirdBuffer® Timed Release Aerosol

REFER TO THE PRODUCT LABEL FOR COMPLETE DIRECTIONS, RATES AND CAUTIONS.
ALWAYS READ AND FOLLOW ALL LABEL DIRECTIONS.

SENSOR METERED AEROSOL DISPENSER FUNCTIONS

- Power On/Off Switch
- Green LED Light - shows battery is operating
- Middle Sensor Light - for day or night only operation
- Red Light (3,000 spray light) when blinking indicates need for battery replacement (should be each new can or 1 month).
- Adjustable Time Set Spraying - set for 7.5 minute/15 minute/30 minute spray intervals (30 minute lasts 1 month)
- Operation Mode Switch - select: 24 hours continuous; day only or night only
 - o 24Hours – operates 24 hours a day
 - o Day Only - functions only when light is sensed; stops automatically when area is dark (must have sunlight)
 - o Night Only - functions only when area is dark; stops automatically when light is detected

INSTRUCTIONS

1. Pull out key packet to open dispenser
2. Remove front cover by pulling from top
3. Select adjustable time set spraying – 7.5 minute / 15 minute / 30 minute
4. Select desired operation mode switch - 24 hour / day only / night only
5. Use mounting bracket as template (to drill holes)
6. Drill hole as marked with 3/16" drill bit
7. Install plastic anchor and secure mounting bracket with screw provided
8. Insert 2 x "D" cell batteries as shown; (Caution: Switch must be in OFF position to prevent premature spray)
9. Insert aerosol can w/nozzle pointed outward
10. To activate, turn outer switch to ON position
11. Reset ON/OFF switch when changing cans and batteries